



mobile maps

User's guide

v2

© 2009 Sygic, s.r.o. All rights reserved.

I. Getting Started	1
Using the “Main screen”	1
Entering an Address	2
Getting directions.....	5
Acquiring GPS Position	6
II. Planning Your Route	7
Navigating to Points of Interest.....	7
Navigating Home	9
Navigating to Your Most Recent Locations	9
III. Changing the Route.....	13
Route Details	13
Modifying the Route.....	14
Map Browsing Mode	15
Itinerary planning	17
IV. Settings	20
Advanced preferences.....	22

End User License Agreement

BY INSTALLING, COPYING OR USING ALL OR ANY PORTION OF THIS SOFTWARE YOU ACCEPT ALL THE TERMS AND CONDITIONS OF THIS AGREEMENT.

This Sygic, s.r.o. End-User License Agreement ("EULA") is a legal agreement between you (either an individual or a single entity) and Sygic, s.r.o. for the Sygic, s.r.o. product known as Sygic Mobile Maps 2009 ("Software Product"). Use of third party materials or data may be subject to other terms and conditions. If you do not agree to terms of this EULA, do not install or use the Software Product; you may, however, return it to your place of purchase for a full refund.

You may have another written agreement directly with Sygic, s.r.o. (e.g., a volume license agreement) that supplements or supersedes all or portions of this agreement.

Sygic, s.r.o. grants you limited rights to use the Software Product (Sygic Mobile Maps 2009) in binary executable form available to you after the installation. Title, ownership rights and intellectual property rights in and to the Software Product remain in Sygic, s.r.o. The Software Product is owned by Sygic, s.r.o. or its suppliers and is protected by European Union copyright and patent laws and international treaty provisions.

THE SOFTWARE COPY IS LICENSED TO YOU, NOT SOLD TO YOU, AND YOU ARE NOT AN OWNER OF ANY COPY THEREOF.

You may install, use, access, display, run or otherwise interact with ("Run") one copy of the Software Product either on a single computer, handheld, Car PC, smart phone ("Computer") or on a single Secure Digital memory card. A license for the Software Product may NOT be shared or used concurrently on different Computers.

ALL RIGHTS NOT EXPLICITLY OR EXPRESSLY GRANTED IN THIS EULA ARE RESERVED BY SYGIC, S.R.O.. THIS EULA DOES NOT GRANT YOU ANY RIGHTS IN CONNECTION WITH ANY TRADEMARKS OR SERVICE MARKS OF Sygic, s.r.o.. License for this Software Product is not for transfer, distribution, or disclosure to third parties or use for the benefit of third parties.

All title, and copyrights in and to the Software Product and to the content which may be accessed through use of it, the accompanying materials and any copies of the Software Product are owned by Sygic, s.r.o. and its suppliers. You may not decompile, disassemble, modify, reverse assemble, reverse engineer or reduce the Software Product of any part thereof or create any derivative works based on the Software except to the extent such activity is expressly permitted by applicable law notwithstanding this limitation.

In certain countries the use of flashpost / speedcamera information might be in conflict with the law and/or regulations. By using such information user agrees to indemnify Sygic and its 3rd party suppliers of any claims related to such flashpost / speedcamera information. Usage is at own risk.

MAP DATA COPYRIGHTS

© 2001 – 2009 Tele Atlas. All rights reserved. This material is proprietary and the subject of copyright protection and other intellectual property rights owned or licensed to Tele Atlas. Tele Atlas is an authorized distributor of selected Statistics Canada computer files under Agreement number 6776 and is an authorized distributor of selected Geomatics Canada computer files. The product includes information copied with permission from Canadian authorities, including © Canada Post Corporation. The use of this material is subject to the terms of a License Agreement. You will be held liable for any unauthorized copying or disclosure of this material.”

Data Source © 2009 Tele Atlas

© BEV, GZ 1368/2009 (Austria)

© DAV (Denmark)

© IGN France; Michelin data © Michelin 2009 (France)

© Ordnance Survey of Northern Ireland (Northern Ireland)

© Norwegian Mapping Authority, Public Roads Administration; © Mapsolutions (Norway)

© Swisstopo (Switzerland)

Topografische ondergrond Copyright © dienst voor het kadaster en de openbare registers, Apeldoorn 2009 (The Netherlands)

© Roskartographia (Russia)

© INCREMENT P CORP. Tele Atlas NV 2009. All rights reserved.

I. Getting Started

Using the “Main screen”



To enter the **main menu**, touch the map area (A) on the main screen, or press the left button on non-touchscreen devices.


To enter the **quick menu**, touch the info panel (B), or right button on non-touchscreen devices.

If the menu contains more pages, you can show the next page using buttons at the bottom of the screen, or by pressing the right button on non-touchscreen devices.




Entering an Address


To navigate to your destination, enter **Main menu**, select **Navigate to...** icon and then choose **Address**.



Next, you will be asked to select **Country**, **City**, **Street** and **House number** or **Street crossing**.



After the destination is entered, the confirmation screen is displayed:



Here you can view the exact position on the map, add it to your list of favorite locations, find nearby parking place, or make a phone call.

Please note, that the **Call** button is available only if the map contains phone number of selected destination, and if the device supports GSM calls.

To confirm the selected destination, push the **Route Me!** button.

If your device knows your current position, your route will be calculated immediately. If your device does not have accurate position, you will get options, how to determine the starting point of the route:



Wait for valid signal
(Recommended)

Your route will be calculated as soon as your current GPS position will be recognized. See the chapter [Acquiring GPS Position](#).



Last valid position

The starting point of your route will be your last position located by GPS (e.g. when you entered the building).



Select from map

(For advanced users only)

Allows you to select any starting point for your route.

After the route is calculated, the route summary is displayed. It shows information about distance and time left to finish, estimated time of arrival and the method used (**Fastest**, **Economic**, **Shortest**, **Pedestrian**, **Bicycle**).

IMPORTANT: By default, the method of calculation is set to **Fastest**. To use a different method, see [Advanced preferences](#).



Getting directions

The calculated route is displayed on the screen as a blue line.




The main navigation screen is providing not only map preview, but also well arranged additional information:

- 1 Next change of direction at crossing
- 2 Distance to next change of direction
- 3 Current street
- 4 Distance to destination
- 5 GPS signal strength
- 6 Current velocity
- 7 Estimated time of arrival at destination
- 8 Current city
- 9 Lane Assistant
- 10 Direction to destination
- 11 Next street to take
- 12 Map zoom

Acquiring GPS Position

In case there is no GPS signal, the screen becomes grey. This can happen under following conditions:

- the device is in a place, where the signal reception from satellites is obstructed by buildings, trees, cables or in a tunnel
- Sygic Mobile Maps settings are set incorrectly
- Device system settings are set incorrectly



Information about signal strength at the bottom of the screen provides extra information:

If the bars or port name is red, re-check the GPS settings (see Installation Manual).

If the bars are grey, stand outside with the good visibility of the sky until the signal is regained and the bars become green. Tap signal bars or select

Main menu >  **GPS Status** to see more detailed GPS information.

After the GPS signal is regained, your driving instructions will be displayed.

II. Planning Your Route

Navigating to Points of Interest

If you need to drive to a gas station, restaurant, hotel, or any other point of interest, enter the

Main menu, select  Navigate to... and then  Point of Interest.

Next, define the area of searching:



Near my position

Finds POI around you



Near address...

Finds POI near the address that you specify



Near destination

Finds POI near the destination of your current trip



In City...



Finds POI in the city you select

How to find a point of interest:

Select a Group (e.g. Sports) and then select the POI type (e.g. Golf Course).

If you don't know the group, use **Show All** button to get a list of all POI types.

If you don't know the POI type, use **Any** button and just enter the name.



You can refine the results by typing a name of the POI. It's not necessary to enter full name – you can just enter a part of it.

NOTE: Distance shown in the list, is relative to the Area that you specified in previous step.

Navigating Home

First, set your home location:

Main menu >  **Settings** >  **Set home location**, and enter your home address.

Once your home address is recorded, you can navigate home by simply selecting **Main menu** >

 **Navigate to...** >  **Home**.

Navigating to Your Most Recent Locations


Once you have navigated to a destination, Sygic Mobile Maps makes it easy to return to the same location. There are several ways of reusing the previously selected destinations.

History

Sygic Mobile Maps keeps track of your most recent destinations. It is easy to reuse them again.

Just enter the **Main menu** > 


Navigate to... >  **History** and start the navigation by selecting your previous destination.



Stored favorite locations

To view a list of your favorite locations, select [Main menu](#) >

[Navigate to...](#) > [Favourite](#)




NOTE: Destinations are added automatically to the list, but if you want to quickly store your current position for future use, just select

 [Memorize position](#) from [Main menu](#). Memorized position will appear in the list with  icon.

How to add a favorite location

- A** Quick Menu (tap information panel on the main screen, or press right button) > **Add to favourites**



- B** **Main menu** >  **Browse map** > Select point on map >  > **Add as POI** > **Favourites**

- C** Store your position during navigation (**Main menu** >  **Memorize position**). Then go to **Main menu** >  **Manage POI** > **Add POI** >  **History** > Select memorized position (marked with  icon)

Previous addresses

When entering an address through **Main menu** > 

Navigate to... >  **Address**, the list of previously selected Countries / Cities / Streets appears, as you go through the address details. They are marked with  icon.

Other icons that you can see during address search:



City



Capital city



City center



Street




Street crossing

III. Changing the Route


Route Details

You can check the calculated route before you start driving.

Enter Main menu >  Route menu.



Choose  Show route summary > Details to get a detailed overview about the route.




The blue highlighted buttons indicate that specific type of road was used.

To avoid it, tap the blue highlighted button. For non-touchscreen devices, press the Up arrow.



Show route instructions



Show route as images



Show route demo



Show on map

Modifying the Route

If you need to make modifications to the existing route, enter the **Main menu** >  **Alternative route.**

You can  **Compute alternative** route in case you don't like the route calculated on the first time.

In case the road ahead of you is closed, you can  **Avoid next...** few kilometers, to calculate a detour.

If you wish to travel through a certain place on your trip, you can set the  **Travel via...** and add a waypoint the same way, as setting the destination in [previous chapters.](#)


If you want to cancel your modifications of the route, use the  **Reset to original** route.

If you wish to cancel the calculated route completely, and use the navigation system only as an indicator of your current position, choose **Main menu** >  **Route** >  **Cancel route** function.

You can find additional information about modification of calculated route in the next chapter.

Map Browsing Mode

Checking the details directly in the map, or even planning the route can be done in map browsing mode. Select **Main menu** >  **Browse map** to start.



On touch screen devices, you can just drag the map to scroll it around. Use arrow buttons on non-touchscreen devices. To zoom the map in and out, use the

numeric keys, or keys # and * of your mobile device.

Available options for the map:



Find...

You can find a position by defining it the standard ways



Show current position



Show entire route



Show city

Shows entire city on map screen



Show/Hide POIs...

You can select, which types of POI types are displayed when browsing the map

You can select a place on the map and then enter the context menu for that point by pressing the  button. Following actions are available:



Navigate there Sets the new destination. Original route will be deleted.



Travel via Adds a new waypoint to your existing route between start and finish.



Continue Adds a new waypoint after the existing destination.



Add as POI Stores the selected point to **Favourites** or other POI category.



Find nearby POI Searches for POIs that are around the selected point.



Avoid... You can select a radius around the point, which will be avoided in the route calculation. Existing route will be recalculated.

Itinerary planning

If you have added some waypoints to your route via **Browse map** or **Alternative route**, you can edit them in **Itinerary**. It is also possible to optimize waypoints within the route, plan a new route or store it for future use.

To edit the current route, open **Main menu** >  **Itinerary** and select the **[Current route]** to see the list of waypoints.



You can see the starting point , the numbered waypoints and the finish . The places that you already visited are grayed out.

You can add a waypoint to the itinerary by clicking the  button.

Waypoint options

If you click any waypoint of the itinerary, you get the following options:



Set as visited Stops navigating to this waypoint and recalculates the route to the following one



Set as finish point Puts the waypoint to the end and moves others upwards in the list



Set as via point Changes the finish point to a normal waypoint



Set as start Stores the waypoint as a start of the route.



Add nearby POI Use this option for example if you have entered a destination of your business trip, and you want to find a nearby hotel.



Move up the selected waypoint in the list.



Move down the selected waypoint in the list.



Delete the waypoint.

Itinerary options

The following actions can be performed with each itinerary (available through the **Options** menu):



Optimize itinerary

Optimizes the waypoint sequence



Save itinerary for future use



Delete itinerary

IV. Settings

To change the factory settings, go to **Main menu** and select  **Settings** icon.

NOTE: Buttons are displaying the situation that will occur when you push them, not the current status. E.g.: Button  means that voice output and sounds are currently enabled. Pushing this button will disable the sounds.



Set to 2D (flat) view



Set 2D North Up



Set 3D view



Set automatic colours



Set night colours



Set daylight colours



Disable sounds



Enable sounds



Volume settings:
Set the sound intensity separately for low driving speed and for high speeds.



Advanced settings:
(for advanced users only)
For more information, see the next chapter.



Planning preferences:
Set the routing algorithm:
Fastest, Economic,
Shortest, Pedestrian,
Bicycle)



Toll charge settings:
Set the preference of paid road segments: avoid them, don't avoid them, or always ask.



GPS hardware:
Detailed configuration of
GPS and TMC hardware.



Signpost settings:
Sets the number of
signpost tables displayed at
one time and the level of
detail (Full, Simplified,
Single line).



Preferred



Other



Rotate display: *
Change the display
orientation (landscape /
portrait).



Keyboard settings: *
You can switch between
preferred keyboard layouts
using  button, that is
available in every
keyboard.



Regional settings:
Set kilometers / miles, time

format and format of GPS
coordinates.



Set language (user
interface)



Set voice (language of
voice instructions)



Switch map:
Load different map material
from your device.



Set home location



Quick Guides
Learn more about major
navigation features.



About Sygic:
Information about version,
device code and available
application memory. Please
provide this information in
communication with Sygic
support.

IMPORTANT: Items marked with
* might not be available in your
device.

Advanced preferences

Main menu >  Settings > 
Advanced settings

1 Avoid U-Turns



Enable lane assistant




Enable Autozoom

Warn if Railway crossing

2 Backlight settings

3 Configuration of Information panel on the main screen



4 Notification settings of maximum speed limit

5 Safety camera settings (if your product includes this data)

Disclaimer

The information contained in this document is the property of Sygic s.r.o. and may be used only for the purposes of operating and supporting the relevant software created by Sygic s.r.o.

Sygic s.r.o. reserves all rights concerning the information contained herein. This document or any part of it may not be reproduced, distributed, or translated into other languages in any way or form except with written approval of Sygic s.r.o.

This document is provided to the user on a 'as is' basis. Although maximum care was taken during preparation of this manual to provide accurate information and to avoid errors, some technical inaccuracies or editorial errors may occur. Sygic s.r.o. accepts no responsibility for such errors.

In the interest of improving the content of the document, Sygic s.r.o. reserves the right to modify, amend or delete any part of the document at any time without prior notice.

For more information and updates, visit www.sygic.com